

Antiperspirant Stick w/ Sonnecone® CM

A non-greasy antiperspirant stick that glides on clear and smooth, has a powdery afterfeel, and leaves no white residue.

<u>SEQUENCE</u>	<u>PERCENT</u>	<u>INGREDIENT</u>	<u>INCI NAME</u>
1	51.00	Sonnecone® CM (Sonneborn Inc.)	Petrolatum
1	9.00	--	Stearyl Alcohol
1	4.00	--	Hydrogenated Castor Oil
2	25.00	--	Aluminum/Zirconium Tetrachlorohydrate-Gly
3	6.00	--	Talc
4	5.00	--	Silica

Procedure:

1. In main beaker, combine Sequence #1 ingredients and heat to 80°C – 85°C with medium speed propeller mixing.
2. Add Sequence #2 and mix until smooth and uniform.
3. Add Sequence #3 and mix until smooth and uniform. Maintain batch temperature at 80°C - 85°C.
4. Add Sequence #4 ingredients and mix until smooth and uniform. Begin cooling.
5. Package in suitable containers at 70°C – 75°C.