

SILICONE FREE ANTIPERSPIRANT STICK WITH LILAC®

An antiperspirant stick that glides on smooth and dry. **Lilac®** provides quick absorption with a silky, non-greasy afterfeel.

<u>SEQUENCE</u>	<u>PERCENT</u>	<u>INGREDIENT</u>	<u>INCI NAME</u>
1	50.00	Lilac® (Sonneborn Inc.)	C14-22 Alkane
1	10.00	--	Stearyl Alcohol
1	5.00	--	Hydrogenated Castor Oil
1	5.00	--	Cetyl Alcohol
2	19.00	--	Aluminum/Zirconium Tetrachlorohydrate-Gly
3	6.00	--	Talc
3	5.00	--	Silica

Procedure:

1. In main beaker, combine Sequence #1 ingredients and heat to 80°C with medium speed propeller mixing. Mix until clear.
2. Slowly add Sequence #2 to Sequence #1 and mix well. Maintain batch temperature at 80°C.
3. Slowly add Sequence #3 ingredients and mix until smooth and uniform.
4. Begin cooling to 75°C.
5. Package in suitable containers at 70°C – 75°C.